

SIGMA

MOUNT CONVERTER MC-11

Lens compatibility

Product line	Category	Lens	AFS	AFC/AFA	DMF
Art	DC	30mm F1.4 DC HSM	○	×	×
	DC	18-35mm F1.8 DC HSM	○	×	×
	DC	50-100mm F1.8 DC HSM	○	×	○
	DG	12-24mm F4 DG HSM	○	×	○
	DG	14-24mm F2.8 DG HSM	○	×	○
	DG	24-35mm F2 DG HSM	○	×	○
	DG	24-70mm F2.8 DG OS HSM	○	×	○
	DG	24-105mm F4 DG OS HSM	○	×	×
	DG	14mm F1.8 DG HSM	○	×	○
	DG	20mm F1.4 DG HSM	○	×	○
	DG	24mm F1.4 DG HSM	○	×	○
	DG	28mm F1.4 DG HSM	○	×	○
	DG	35mm F1.4 DG HSM	○	×	×
	DG	40mm F1.4 DG HSM	○	×	○
	DG	50mm F1.4 DG HSM	○	×	○
	DG	70mm F2.8 DG MACRO	○	×	○
	DG	85mm F1.4 DG HSM	○	×	○
	DG	105mm F1.4 DG HSM	○	×	○
	DG	135mm F1.8 DG HSM	○	×	○
Contemporary	DC	17-70mm F2.8-4 DC MACRO OS HSM	○	×	×
	DC	18-200mm F3.5-6.3 DC MACRO OS HSM	○	×	×
	DC	18-300mm F3.5-6.3 DC MACRO OS HSM	○	×	×
	DG	100-400mm F5-6.3 DG OS HSM	○	×	○
	DG	150-600mm F5-6.3 DG OS HSM	○	×	○
Sports	DG	60-600mm F4.5-6.3 DG OS HSM	○	×	○
	DG	70-200mm F2.8 DG OS HSM	○	×	○
	DG	120-300mm F2.8 DG OS HSM	○	×	×
	DG	150-600mm F5-6.3 DG OS HSM	○	×	○
	DG	500mm F4 DG OS HSM	○	×	○

※ AF-C and AF-A are not supported.

※ Some lenses are not compatible with DMF.

※ To use DMF, the settings must be changed using the USB DOCK (sold separately).

※ Please use MF when shooting movies.