

Compatibility Table

PA-PTTL PENTAX ELECTRONIC FLASH EF-610 DG SUPER

It is possible to use TTL Auto, Manual Flash, Autozoom Head, AF Auxiliary Lamp, Designated Slave Flash, Normal Slave Flash, Rear-Curtain Synchro, Multi Flash functions, Red-Eye Reduction, High-Speed Synchro and Wireless Flash function. Manual switching of the amount of light is 1/1 - 1/64; Auto Power Off function shuts off 180seconds after use.

	TTL Auto	Autozoom Head	Manual Flash	AF Auxiliary Lamp	Red-Eye Reduction Function	High-Speed Synchro	Wireless Flash	Designated Slave Flash*1	Normal Slave Flash	Rear Curtain Synchro
*istD	P-TTL	✓	✓	✓	✓	✓	✓	✓	✓ *2	✓
*istDS	P-TTL	✓	✓	✓	✓	✓	✓ *1	✓	✓ *3	✓
*istDS2	P-TTL	✓	✓	✓	✓	✓	✓ *1	✓	✓ *3	✓
*istDL	P-TTL	✓	✓	✓	✓	✓	✓ *1	✓	✓ *3	✓
*istDL2	P-TTL	✓	✓	✓	✓	✓	✓ *1	✓	✓ *3	✓
K10D	P-TTL	✓	✓	✓	✓	✓	✓	✓	✓ *3	✓
K20D	P-TTL	✓	✓	✓	✓	✓	✓	✓	✓ *3	✓
K-30	P-TTL	✓	✓	✓	✓	✓	✓	✓	✓ *3	✓
K-50	P-TTL	✓	✓	✓	✓	✓	✓	✓	✓ *3	✓
K100D / K110D	P-TTL	✓	✓	✓	✓	✓	✓ *1	✓	✓ *3	✓
K100D Super	P-TTL	✓	✓	✓	✓	✓	✓ *1	✓	✓ *3	✓
K200D	P-TTL	✓	✓	✓	✓	✓	✓	✓	✓ *3	✓
K-m	P-TTL	✓	✓	✓	✓	✓	✓	✓	✓ *3	✓
K-r	P-TTL	✓	✓	✓	✓	✓	✓	✓	✓ *3	✓
K-x	P-TTL	✓	✓	✓	✓	✓	✓	✓	✓ *3	✓
K-3	P-TTL	✓	✓	✓	✓	✓	✓	✓	✓ *3	✓
K-3II	P-TTL	✓	✓	✓	✓	✓	✓ *1	✓	✓ *3	✓
K-5	P-TTL	✓	✓	✓	✓	✓	✓	✓	✓ *3	✓
K-5II / K-5IIs	P-TTL	✓	✓	✓	✓	✓	✓	✓	✓ *3	✓
K-7	P-TTL	✓	✓	✓	✓	✓	✓	✓	✓ *3	✓
K-s1	P-TTL	✓	✓	✓	✓	✓	✓ *1	✓	✓ *3	✓
K-s2	P-TTL	✓	✓	✓	✓	✓	✓ *1	✓	✓ *3	✓

*1 It can be used as a Master unit only by using two DG SUPER units.

*2 Please cancel pre-flash when using built-in flash or an external flashgun unit.

*3 Built-in flash cannot be used. Please set your Master unit to Manual Flash mode.