

Compatibility Table

SA-STTL SIGMA ELECTRONIC FLASH EF-610 DG SUPER

It is possible to use TTL Auto, Manual Flash, Autozoom Head, AF Auxiliary Lamp, Red-eye Reduction function, High-speed synchro (FP), Wireless Flash (except SD9), Designated Slave Flash, Normal Slave Flash, Rear-curtain Synchro Flash, Exposure Compensation Function, Multi Flash and Modeling Flash functions. Manual switching of the amount of light is from 1/1 to 1/128. Auto Power-Off function shuts off 300 seconds after use. DP Merrill series and dp Quattro series can be used only in TTL Auto, Manual Flash, Red-eye Reduction function*5, Exposure Compensation Function*5 and Modeling Flash functions.

	TTL Auto	Autozoom Head	Manual Flash	AF Auxiliary Lamp	Red-Eye Reduction Function	High-Speed Synchro	Wireless Flash	Designated Slave Flash *2	Normal Slave Flash	Rear Curtain Synchro	Exposure Compensation Function
SD9	STTL	✓	✓	✓	✓	✓	×	✓	✓ *3	✓ *3	✓
SD10	STTL	✓	✓	✓	✓	✓	✓ *1	✓	✓ *3	✓ *3	✓
SD14	STTL	✓	✓	✓	✓	✓	✓	✓	✓ *4	✓ *3	✓
SD15	STTL	✓	✓	✓	✓	✓	✓	✓	✓ *4	✓ *3	✓
SD1	STTL	✓	✓	✓	✓	✓	✓	✓	✓ *4	✓	✓
SD1 Merrill	STTL	✓	✓	✓	✓	✓	✓	✓	✓ *4	✓	✓
sd Quattro	STTL	✓	✓	✓ *5	✓ *7	✓ *7	✓	✓	✓	✓ *7	✓
sd Quattro H	STTL	✓	✓	✓ *5	✓ *7	✓ *7	✓	✓	✓	✓ *7	✓
DP1 Merrill	STTL	×	✓	×	✓ *5	×	×	×	×	×	✓ *5
DP2 Merrill	STTL	×	✓	×	✓ *5	×	×	×	×	×	✓ *5
DP3 Merrill	STTL	×	✓	×	✓ *5	×	×	×	×	×	✓ *5
dp1 Quattro	STTL	×	✓	×	✓ *5	×	×	×	×	×	✓ *5
dp2 Quattro	STTL	×	✓	×	✓ *5	×	×	×	×	×	✓ *5
dp3 Quattro	STTL	×	✓	×	✓ *5	×	×	×	×	×	✓ *5
dp0 Quattro *6	STTL	×	✓	×	✓ *5	×	×	×	×	×	✓ *5
fp	STTL	✓	✓	✓ *5	✓ *7	×	✓	×	✓	✓ *7	✓

*1 It can be used when two DG SUPER units are used.

*2 It can be used as a Master unit only by using two DG SUPER units.

*3 Please set your flash to Normal Slave mode.

*4 Built-in flash cannot be used. Please set your Master unit to Manual Flash mode.

*5 This setting is only available on camera.

*6 Please make sure that a built-in wide panel is slid out during the use.

*7 This setting is only available on flash.