SIGMA

EO-ETTL II (for Canon) ELECTRONIC FLASH EF-630

(as of August 2021.) This flash correspond with the E-TTL II auto exposure type EOS DSLR cameras listed below.

	TTL Auto	Autozoom Head	Manual Flash	Multiple Flash	AF Assist light *1	Wireless Flash (built-in flash)	Wireless Flash (external flash) *2	Designated Receive function *2	Normal Receive function *3	Rear-curtain Sync flash function	FP flash (high-speed sync)	Exposure control function	FEB photography	FE Lock photography
EOS-1D Mark III	E-TTL II	~	~	~	~	×	~	~	~	~	~	~	~	~
EOS-1D Mark IV	E-TTL II	✓	~	~	~	×	~	~	~	~	✓	~	~	~
EOS-1D X	E-TTL II	✓	~	~	~	×	~	~	~	~	✓	~	~	~
EOS-1D X Mark II	E-TTL II	~	~	~	~	×	~	~	~	~	•	~	~	~
EOS 5D Mark II	E-TTL II	✓	~	~	~	×	✓	~	~	~	✓	~	~	~
EOS 5D Mark III	E-TTL II	~	~	~	~	×	~	~	~	~	•	~	~	~
EOS 5D Mark IV	E-TTL II	~	~	~	~	×	✓	~	~	~	•	~	~	~
EOS 5Ds	E-TTL II	~	~	~	~	×	~	~	~	~	✓	~	~	~
EOS 5Ds R	E-TTL II	✓	~	~	~	×	~	~	~	~	✓	~	~	~
EOS 6D	E-TTL II	✓	~	~	~	×	✓	~	~	~	✓	~	~	~
EOS 7D	E-TTL II	✓	~	~	~	~	✓	~	~	~	✓	~	~	~
EOS 7D Mark II	E-TTL II	~	~	~	~	✓	✓	~	~	~	✓	~	~	~
EOS 50D	E-TTL II	✓	~	~	~	×	✓	~	~	~	✓	~	~	~
EOS 60D	E-TTL II	✓	~	~	~	~	~	~	~	~	✓	~	~	~
EOS 70D	E-TTL II	✓	~	~	~	~	✓	~	~	~	✓	~	~	~
EOS 80D	E-TTL II	~	~	~	~	~	~	~	~	~	✓	~	~	~
EOS 8000D, EOS REBEL T6s, EOS 760D	E-TTL II	•	~	•	•	~	~	•	•	•	•	•	•	•
EOS 9000D, EOS 77D	E-TTL II	~	~	~	~	~	~	~	~	~	~	~	~	~
EOS Kiss X2, EOS REBEL Xsi, EOS 450D	E-TTL II	•	•	~	•	×	•	•	•	•	•	•	•	•
EOS Kiss X3, EOS REBEL T1i, EOS 500D	E-TTL II	~	•	~	•	×	~	~	~	•	•	~	•	~
EOS Kiss F, EOS REBEL XS, EOS 1000D	E-TTL II	~	~	~	~	×	•	•	•	~	~	~	•	•
EOS Kiss X4, EOS REBEL T2i, EOS 550D	E-TTL II	~	~	~	•	×	~	•	~	•	•	~	•	•
EOS Kiss X5, EOS REBEL T3i, EOS 600D	E-TTL II	~	•	~	•	~	•	•	•	~	•	~	•	•
EOS Kiss X6i, EOS REBEL T4i, EOS 650D	E-TTL II	~	~	~	~	~	~	~	•	•	~	~	•	•
EOS Kiss X7i, EOS REBEL T5i, EOS 700D	E-TTL II	~	~	•	•	•	~	•	•	~	•	~	•	•
EOS Kiss X7, EOS REBEL SL1, EOS 100D	E-TTL II	~	•	•	~	×	~	•	•	~	•	~	•	•
EOS Kiss X9, EOS REBEL SL2, EOS 200D	E-TTL II	~	~	~	~	×	•	•	•	•	•	~	•	•
EOS Kiss X10, EOS REBEL SL3, EOS 250D/200D II	E-TTL II	•	•	~	•	×	•	~	•	~	•	•	•	~
EOS Kiss X8i, EOS REBEL T6i, EOS 750D	E-TTL II	~	•	~	~	~	•	•	•	~	•	~	•	•
EOS Kiss X9i, EOS REBEL T7i, EOS 800D	E-TTL II	~	~	~	~	•	•	~	~	•	•	~	•	~
EOS Kiss X50, EOS REBEL T3, EOS 1100D	E-TTL II	•	~	•	•	×	~	~	•	•	~	•	•	•
EOS Kiss X70, EOS REBEL T5, EOS 1200D	E-TTL II	~	~	~	•	×	~	•	•	•	•	~	•	•
EOS Kiss X80, EOS REBEL T6, EOS 1300D	E-TTL II	~	•	•	•	×	~	•	•	~	•	~	•	•
EOS Kiss X90, EOS REBEL T7, EOS 2000D/1500D	E-TTL II	•	•	×	•	×	•	•	•	•	•	•	•	•
EOS M3	E-TTL II	✓	~	~	×	×	~	~	~	~	~	~	~	✔ *4
EOS M5	E-TTL II	~	~	~	×	×	~	~	~	~	~	~	~	✔ *4
EOS M6	E-TTL II	~	~	~	×	×	~	~	~	~	~	~	~	✔ *4
EOS KISS M, EOS M50	E-TTL II	~	~	~	×	×	~	~	~	~	~	~	~	✔ *4
EOS R	E-TTL II	~	~	~	×	×	~	~	~	~	•	~	~	✔ *4
EOS RP	E-TTL II	~	~	~	×	×	~	~	~	~	•	~	~	✓ *4

¹ Limited with the center focus point. Furthermore the flash will not work during live view.

2 Using two EF-630s, the flash attached on the camera's hotshoe will be used as the calculate flash.

3 The built-in flash cannot be used. Please use the manual flash mode to use the external flash attached on the camera hotshoe.

4 Pre-flash fires when the FEL button is pressed.